


**preeflow® eco-CONTROL
EC200-K / -B**



Interface description

Connections

| | Designation | Function, description |
|----|---------------------------|--|
| 13 | Pressure OUT | Output compressed air, connection to supply tank / cartridge / medium tank |
| 14 | Pressure IN | Input compressed air, hose connection, 4 mm (Quickstar) |
| 15 | System plugs | See the description above for the pin-outs |
| 16 | Motor 1 / 2 | For dispensers 1 and 2 |
| 17 | Sensor | Input level monitoring medium |
| 18 | Foot switch | Foot switch for hands-free operation |
| 19 | System plugs | See the description above for the pin-outs |
| 20 | RS 232 | Data transfer with PC, interface. preparation |
| 21 | +24 V/DC 100 VA | Mains plug, connection for power supply |
| 22 | Chipcard (SD memory card) | Chipcard reader (SD memory card) |
| 23 | Connection to earth | Equipotential bonding, at connection 16 |



Brief overview of system plugs

System plugs (15)


| | |
|------------------------------|-------------------|
| <input type="radio"/> 1C | Dosing |
| <input type="radio"/> 1E | |
| <input type="radio"/> 2C | Remote mode |
| <input type="radio"/> 2E | |
| <input type="radio"/> 3C | |
| <input type="radio"/> 3E | not allocated yet |
| <input type="checkbox"/> SS | ext. start |
| <input type="checkbox"/> A1 | Analog 1 0-10 V |
| <input type="checkbox"/> A2 | Analog 2 4-20 mA |
| <input type="checkbox"/> GND | GND analog |
| <input type="checkbox"/> GND | GND sensor |
| <input type="checkbox"/> GND | GND sensor |

System plugs (19)

| | |
|--------------------------|---------------------|
| <input type="radio"/> 0A | Sensor fill level |
| <input type="radio"/> 0C | |
| <input type="radio"/> 1A | not allocated yet |
| <input type="radio"/> 1C | |
| <input type="radio"/> FC | Level alarm |
| <input type="radio"/> FE | |
| <input type="radio"/> RC | Ready for operation |
| <input type="radio"/> RE | |
| <input type="radio"/> EC | Error output |
| <input type="radio"/> EE | |


I = input
O = output

Sensor (17)



- 1 0 VDC (GND)
 - 2 Switch output
 - 3 +24 VDC internal
- Matching plug Part No. 20056

Foot switch (18)



- 1 Contact via make contacts
 - 2 Contact via make contacts
 - 3 not set
- Matching plug Part No. 20055

(view of rear of controller EC200)

Description

Analog inputs at terminals:

analog inputs, reference potential GND terminals.

SS=0/24 V digital input start/stop. (High=start process)

A1=analog input for 0-10 V

A2=analog input for 4-20 mA

Digital opto-coupled inputs at terminals:

The internal LED's of the opto-couplers are produced with anodes and cathodes. Max. current at 24 V approx.

10 mA. Low: 0..1.5V, High 12..24V

| | | |
|---|----|--|
| I | 0A | function level sensor (digital input signal) |
| I | 0C | |

Digital opto-coupled outputs at terminals:

Max. permissible voltage 30 V, max. current 10 mA. The transistor (NPN) of each opto-coupler has a collector and emitter.

| | | |
|---|----|--|
| O | 1C | Dosing (dosing process running=transistor switched through) |
| O | 1E | |
| O | 2C | Remote mode. Transistor low resistance = Control system in remote mode. |
| O | 2E | Transistor high resistance = Control system in local mode or no ecoREMOTE connected. |
| O | FC | Level alarm (alarm blocks the transistor) |
| O | FE | |
| O | RC | EC200 ready for operation (no error=transistor switched through) |
| O | RE | |
| O | EC | Error output (pressure+overcurrent blocks the transistor) |
| O | EE | |

Digital inputs at plug connectors:
Direct inputs without opto-couplers. Low: 0..1.5V, High 12..24V
Plug Sensor (17) 3-pole. Pin1= internal GND, Pin2=signal, Pin3=internal +24 V
Sensor function: Level monitoring digital
Foot switch function: Foot switch digital

Outputs at plug connectors:
Motor1 and Motor2: Function: Connection of eco-PEN450 or 600

Logical links of the outputs:

Ready for operation. The transistor is blocked in the switched-off state. It is switched through after switching on and successful initialization. It has a high ohm value if there is either an under-/overpressure or an overcurrent.

Error output. The transistor is blocked in the switched-off state. It is switched through after switching on and successful initialization. It has a high ohm value if there is either an under-/overpressure or an overcurrent. If one of the two errors applies, it is not possible to initiate a dosing operation.

Level alarm. The transistor is blocked in the switched-off state. It is switched through after switching on and successful initialization. It has a high ohm value if the level sensor connected to 10A and 10C does not allow any current to flow through the opto-coupler.


Dosing. The transistor has a high ohm value in the switched-off state and after initialization. It is only switched through during a dosing operation.

Connections of the level sensor

The device must be informed at which connection the level sensor has been connected. This is necessary because the sensor supplies a high signal if there is no level warning. The selection of the connection is done via system and error messages via the level monitoring function. There it can be set as follows:

| External level sensor | Monitored sensor input |
|-----------------------|-----------------------------------|
| OFF | 3-pole socket, plug 17 |
| ON | Terminals I0A I0C, system plug 19 |

Inputs




Outputs



External switch + load are examples!

Digital Outputs: max 30VDC / 10mA, NPN-Transistor
 Digital Inputs (Opto-coupler): max 10mA at 24VDC, <1,5V = 0; >12...24V = 1
 Digital Inputs (without Opto-coupler): <1,5V = 0; >12...24V = 1
 Inputs (I0, I1): C = Cathode; A = Anode
 Outputs (O1..3; O5, O8, O9): C = Collector; E = Emitter





Digital Outputs: max 30VDC < 10mA, NPN-Transistor
 Digital Inputs (Opto-coupler): max. 10mA at 24VDC, <1,5V = 0; >12...24V = 1
 integrated Resistor 2kΩ
 Digital Inputs (without Opto-coupler): <1,5V = 0; >12...24V = 1
 Inputs (I0, I1): C = Cathode; A = Anode
 Outputs (O1..3; OF, OR, OE): C = Collector; E = Emitter

eco-CONTROL EC200-K

Interface description

preeflow®
by ViscoTec





Überreicht durch:



Gewerbepark 13
85402 Kranzberg
Germany

www.dosieren.de



info@preeflow.com
www.preeflow.com